



PLAYGROUNDS & SITE AMENITIES

GLIDE ELBOW MECHANISM

Step-by-Step Instructions

Needed Supplies

- 2 individuals
- 2 ladders
- 1/4 hex key
- wrench or cordless drill

Fabric Removal

- STEP 1** Before removal, make sure the area where the fabric will land is clean.
- STEP 2** Mark one corner of the post and fabric with a corresponding letter or other marking so the shade goes back on correctly.
- STEP 3** Using the 1/4 hex key, loosen and remove the glide elbow cover plate.
- STEP 4** Activate the glide elbow using a socket wrench or a cordless drill. This action turns the threaded rod connection nut counter clockwise until the protrusion fabric hook moves to loosen the fabric enough to remove.
- STEP 5** Repeat on all corners.
- STEP 6** Lower the fabric and fold or roll it for proper storage.

Reinstall Fabric

- STEP 1** To reinstall fabric, unfold it and properly identify the marked corner with the corresponding column and position the fabric.
- STEP 2** Tie rope to two corners and throw the rope over the frame.
- STEP 3** Pull the rope to adequately raise the fabric back into place.
- STEP 4** Spread the fabric over the frame.
- STEP 5** Attach the fabric to the corner and remove the rope.
- STEP 6** Activate the glide elbow by turning the rod connection nut clockwise until semi tight.
- STEP 7** Replace the cover plate and be sure to position the horizontal drain slit at the bottom of the pipe.
- STEP 8** Tightly secure the hex nut.
- STEP 9** Repeat at each corner until the fabric is uniformly fitted back onto the frame.