


USER GROUP: 5-12 Years, Adult
RECOMMENDED CREW: 1 Person
TOOLS REQUIRED:
• Level, Square
• Auger / Post Hole Digger / Shovel
• Drill Bits: None
INSTALLATION TIME: 1 Hour
WEIGHT: 56 lbs.
CONCRETE REQUIRED: (4) 80lb. bags
NOTE: Concrete must have a minimum rating of 2,500 psi and must be mixed per manufacturer's recommendations.

PRE-INSTALLATION CHECK:
Customer is responsible for verifying materials received by comparing received items with packing list. If any parts are missing or damaged, contact your local sales representative immediately.

Supplier is not responsible for items discovered missing after 72 hours from time of delivery.

Before beginning installation, all installers must read and understand the Installation Introduction manual as supplied. If you did not receive a copy, or if you have any questions regarding any information in the Installation Instructions or this Installation Guideline, contact your local sales representative.





STEP 1

Prepare footing holes. Refer to site plan drawing and site elevation drawing for placement of all structures. Installer is responsible for proper location of all structures. Footing hole spacing is shown at right. Footing holes must be 12" diameter and 18" deep. Bottom 3" of footing holes should be filled with aggregate. See Detail 1-1. Bottoms of wheels of structure should be flush or up to 3" above grade/surfacing. Adjust footing hole depth as needed to ensure elevation. Place assembly into footing holes and plumb. Fill footing holes with concrete level with grade/surfacing. Allow concrete to cure based upon manufacturer's instructions. All concrete must be fully cured before use of structure. Installation is complete.

Detail 1-1

